


Knightronix™ KnightLighter™ Automatic Gaslight Igniter

Installation Instructions

6V Battery Side-Mount Igniter and Open Flame Burner (With QuickConnect Gas Light Plug-in Receptacle Kit – KNQPR4 or KNQPR5)


The KnightLighter™ igniter with the solenoid valve mounted on the side of the igniter box is designed to be installed in the bottom of the gaslight head. It should fit almost on the floor of the gaslight so as to be inconspicuous.



**KNA1-6BI-DF-S
KnightLighter Automatic
Gaslight Igniter**



**KnightLighter 6V Battery Side-mount Igniter
with Open Flame Burner; installed in aluminum
six-sided gaslight.**



**Gas line connection with optional
QuickConnect fittings.**



**KnightLighter QuickConnect Receptacle
in bottom of gaslight head.**

**6V Battery Side-Mount Igniter and Open Flame Burner
(with QuickConnect Gas Light Plug-in Receptacle Kit – KNQPR4 or KNQPR5)**

Upgrading and new installation procedures for installing the 6V Battery igniter in the MHP VK-7A or GLM 1200 2-mantle burner gaslights or equivalent post, wall, or pier mount gaslights. (Start at instruction 7 for installations in new gaslight heads.)

1. Turn off the gas to the gaslight at the source going to the gaslight so that the gaslight with its manual valve can be removed.
2. Remove the glass from the gaslight.
3. Loosen the screws that hold the gaslight on the pier/post and raise the gaslight to allow disconnecting the manual valve from the copper tubing.
4. Remove the burner from the manual valve and save the burner and chimney.
5. Remove the manual valve.
6. Clean and repair the gaslight if necessary.

Start here for installation in new gaslight head:

7. The quick-connect fitting with modified manual shut-off valve shall be pre-assembled (See Figure 1) before installing in the light. **NOTE:** Apply TFE Paste thread sealer to each connection if not already applied.




Figure 1

8. Install the quick-connect fitting by inserting into the pre-existing access hole in the base of the gaslight. (See Figure 2). Attach and tighten the 7/8" valve nut.



Figure 2

9. Drill access hole for the Daylight Sensor in either of the two locations shown. Make sure the daylight sensor is not pointed toward any bright lights (street lights, Holiday lights, etc.) The daylight sensor must have a clear view of daylight for the lamp to shut off during the day. (See Figure 3)



Figure 3

10. Install the Igniter/Open Flame Burner (See Figure 4) in the gaslight by snapping the unit into the quick connect fitting. Check to make sure connection is secure. (Batteries should already be installed in the battery holder.)





Figure 4

11. Reinstall the gaslight on the post or pier; apply TFE Paste thread sealer and connect the 1/4" copper gas line by tightening the 1/4" Flare Nut onto the input to the gaslight valve. If using another type of valve, attach a 1/4" x 1/8" Flare fitting if necessary. Push the copper tubing down into the post (for post installations).
12. Align the igniter and insert the daylight sensor (photo sensor on yellow and black twisted wires) into the access hole that was drilled in step 9. Be sure that the daylight sensor does not view the lamp flame or reflections off the glass.
13. The back of the daylight sensor is also sensitive to light; cover it sheath or with black electrical tape so the lamp does not shine on the back side of the plastic sensor.
14. Check the alignment of the lamp sensor; verify that it is pointed up toward the position of the flame.
15. Apply sheath to lamp/flame sensor (Optional).

16. Check the alignment of the ignition probe. **The igniter/burner is a single unit with an open wire probe leading from the high voltage transformer to the probe gap at the side of the open flame. The probe shall be aligned crosswise of the slit and be positioned just within the gas/air boundary of the flame coming out of the side of the burner slit. The gap shall be about 3/16 to 1/4 inch. (See photos below.) No ceramic insulator or bracket is required. This arrangement has the added advantage that soot will not build up on the probe.**



17. Check the gas line for leaks using bubble water solution or a gas detector around the fittings. If any leaks are present, correct them before powering the igniter. Turn on the gas.
18. Install 4 AA batteries in the battery holder, if not already installed.
19. Snap together the connector on the 6VDC battery pack to the input power wire connector on the KnightLighter™ Igniter. The LED on top of unit will flash twice to signal power on.
20. Replace the glass in the gaslight.

This completes the installation of the automatic gaslight.

Quick Checkout of the Automatic gaslight:

1. If using in the battery holder, install 4 AA batteries if not already installed.
2. Snap together the connector on the 6VDC battery pack/holder to the input power wire connector on the KnightLighter™ Igniter. The LED on top of unit will flash twice to signal power on.
3. Cover the lamp sensor and the daylight sensor with black tape or sensor cover to simulate darkness (other colors or types of tape do not block all light.).
4. After 6 seconds, there will be 1 spark and 2 flashes; valve will open and sparks shall appear across the spark probe to the open flame burner and the solenoid valve shall open and the gaslight shall light.
5. Remove the tape/sensor cover from the flame sensor and the gaslight shall remain lit.
6. Remove the tape from the daylight sensor and the lamp shall go out in about 3 minutes.
7. Replace the glass panels.
8. Remove the tape from the Flame Photo-Sensor and the gaslight shall remain lit.
9. This completes the gaslight checkout. It is ready to operate.